

How to measure your sidelites.



Here is a typical front door system with a single 3/0 6/8 (36" x 80") front door, 2 sidelites and (in this case) a segmented transom. The sidelites fit in the pocket of the door frame next to your door.



The width of your sidelite is easiest to measure if you go outside your home and measure across the flat part of your sidelite. You will be measuring the width of the pocket. (From Point A to Point B) This measurement is usually 9" or 11". The frame overlaps the sidelite by $\frac{1}{2}$ " on each side so this equals a 10" or 12" sidelite - two very common sizes.

Finally, the height of the sidelite is easy to measure. The sidelites are usually either the same size or just a little taller than your door. So just measure the height of your door.